

AT 50/50A/150



1	EXTERNAL SUPPR NEGATIVE
2	GROUND
3	GROUND
4	DIMMER * †
5	DIGITIZER COMMON
6	A2
7	A1
8	A4
9	B4
10	B2
11	C2
12	B1
13	C4
14	C1
15	EXT SUPPR POSITIVE
16	+14 VOLT
17	REMOTE IDENT
18	SWITCHED DIGITIZER POWER OUT

NOTES

* † ON AT50 AND AT50A, THIS INPUT IS FOR 14V DIMMER ONLY. ON AT150, THE DIM VOLTAGE MAY BE SELECTED ON THE UNIT SO THIS INPUT IS FOR 14 OR 28V DIMMER.